



Human hepatitis B virus pre S1 antigen (HBV preS1-Ag) ELISA Kit

Catalog Number. CSB-EQ028068HU

For the qualitative determination of human hepatitis B virus pre S1 antigen (HBV preS1-Ag) concentrations in serum, plasma.

This package insert must be read in its entirety before using this product.

If You Have Problems

Technical Service Contact information

Phone: 86-27-87582341

Fax: 86-27-87196150

Email: tech@cusabio.com

Web: <https://www.cusabio.com/>

In order to obtain higher efficiency service, please ready to supply the lot number of the kit to us (found on the outside of the box).

PRINCIPLE OF THE ASSAY

This assay employs the qualitative enzyme immunoassay technique. The microtiter plate provided in this kit has been pre-coated with preS1Ab. Samples are pipetted into the wells with Horseradish Peroxidase (HRP) conjugated HBs antibody. Following a wash to remove any unbound reagent, a substrate solution is added to the wells and color develops in proportion to the amount of human HBV preS1-Ag bound in the initial step. The color development is stopped and the intensity of the color is measured.

SPECIFICITY

This assay has high sensitivity and excellent specificity for detection of human HBV preS1-Ag. No significant cross-reactivity or interference between human HBV preS1-Ag and analogues was observed.

Note: Limited by current skills and knowledge, it is impossible for us to complete the cross-reactivity detection between human HBV preS1-Ag and all the analogues, therefore, cross reaction may still exist.

PRECISION

Intra-assay Precision (Precision within an assay): CV%<15%

Three positive samples were tested twenty times on one plate to assess.

Inter-assay Precision (Precision between assays): CV%<15%

Three positive samples were tested in twenty assays to assess.

LIMITATIONS OF THE PROCEDURE

- **FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES.**
- The kit should not be used beyond the expiration date on the kit label.
- Do not mix or substitute reagents with those from other lots or sources.
- Any variation in operator, pipetting technique, washing technique, incubation time or temperature, and kit age can cause variation in binding.
- This assay is designed to eliminate interference by soluble receptors, binding proteins, and other factors present in biological samples. Until all factors have been tested in the Immunoassay, the possibility of interference cannot be excluded.

MATERIALS PROVIDED

Reagents	Quantity
Coated assay plate	1(96 wells)
Negative Control	1 x 0.4 ml
Positive Control	1 x 0.4 ml
HRP-conjugate	1 x 6 ml
Wash Buffer (20 x concentrate)	1 x 50 ml
Substrate A	1 x 6 ml
Substrate B	1 x 6 ml
Stop Solution	1 x 6 ml
Adhesive Strip (For 96 wells)	4
Instruction manual	1

STORAGE

Unopened kit	Store at 2 - 8°C. Do not use the kit beyond the expiration date.
Opened kit	May be stored for up to one month at 2 - 8° C.

***Provided this is within the expiration date of the kit.**

OTHER SUPPLIES REQUIRED

- Microplate reader capable of measuring absorbance at 450 nm, with the correction wavelength set at 630 nm.
- An incubator which can provide stable incubation conditions up to 37°C±0.5°C.
- Squirt bottle, manifold dispenser, or automated microplate washer.
- Absorbent paper for blotting the microtiter plate.
- 100ml and 500ml graduated cylinders.
- Deionized or distilled water.
- Pipettes and pipette tips.
- Test tubes for dilution.

PRECAUTIONS

The Stop Solution provided with this kit is an acid solution. Wear eye, hand, face, and clothing protection when using this material.

SAMPLE COLLECTION AND STORAGE

- **Serum** Use a serum separator tube (SST) and allow samples to clot for two hours at room temperature or overnight at 4°C before centrifugation for 15 minutes at 1000 ×g. Remove serum and assay immediately or aliquot and store samples at -20°C or -80°C. Avoid repeated freeze-thaw cycles.
- **Plasma** Collect plasma using EDTA, or heparin as an anticoagulant. Centrifuge for 15 minutes at 1000 x g, 2 - 8°C within 30 minutes of collection. Assay immediately or aliquot and store samples at -20°C or -80°C. Avoid repeated freeze-thaw cycles. Centrifuge the sample again after thawing before the assay.

Note:

1. CUSABIO is only responsible for the kit itself, but not for the samples consumed during the assay. The user should calculate the possible amount of the samples used in the whole test. Please reserve sufficient samples in advance.
2. Samples to be used within 2 days may be stored at 2-8°C, otherwise samples must be stored at -20°C (≤1month) or -80°C (≤2month) to avoid loss of bioactivity and contamination.
3. Grossly hemolyzed samples are not suitable for use in this assay.
4. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
5. Fresh samples without long time storage are recommended for the test. Otherwise, protein degradation and denaturalization may occur in those samples and finally lead to wrong results.

REAGENT PREPARATION**Note:**

- **Kindly use graduated containers to prepare the reagent. Please don't prepare the reagent directly in the Diluent vials provided in the kit.**
- Bring all reagents to room temperature (18-25°C) before use for 30min.
- Distilled water is recommended to be used to make the preparation for reagents. Contaminated water or container for reagent preparation will influence the detection result.

Wash Buffer(1x)- If crystals have formed in the concentrate, warm up to room temperature and mix gently until the crystals have completely dissolved. Dilute 50 ml of Wash Buffer Concentrate (20 x) into deionized or distilled water to prepare 1000 ml of Wash Buffer (1 x).

ASSAY PROCEDURE

Bring all reagents and samples to room temperature before use. Centrifuge the sample again after thawing before the assay. It is recommended that all samples and controls be assayed in duplicate.

1. Prepare all reagents, and samples as directed in the previous sections.
2. Refer to the Assay Layout Sheet to determine the number of wells to be used and put any remaining wells and the desiccant back into the pouch and seal the ziploc, store unused wells at 4°C.
3. Set a Blank well without any solution.
4. Set three **Negative Control** wells, one **Positive Control** well. Add 50µl of **Negative Control, Positive Control** and **sample** per well.
5. Cover with the adhesive strip provided. Incubate for 30 minutes at 37°C.
6. Aspirate each well and wash, repeating the process four times for a total of five washes. Wash by filling each well with Wash Buffer (200µl) using a squirt bottle, multi-channel pipette, manifold dispenser, or autowasher, and let it stand for 30-60 seconds, complete removal of liquid at each step is essential to good performance. After the last wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean paper towels.
7. Add 50µl of **HRP-conjugate** to each well (not to Blank well). Cover the microtiter plate with a new adhesive strip. Incubate for 30 minutes at 37°C.
8. Repeat the aspiration/wash process for five times as in step 6.
9. Add 50µl of **Substrate A** and 50µl **Substrate B** to each well. Incubate for 15 minutes at 37°C. **Protect from light.**
10. Add 50µl of **Stop Solution** to each well, gently tap the plate to ensure thorough mixing.
11. Take blank well as zero, determine the optical density of each well within 10 minutes, using a microplate reader set to 450 nm.

Note:

1. The final experimental results will be closely related to validity of the products, operation skills of the end users and the experimental environments.
2. Samples or reagents addition: Please carefully add samples to wells and mix gently to avoid foaming. Do not touch the well wall as possible. For each step in the procedure, total dispensing time for addition of reagents or samples to the assay plate should not exceed 10 minutes. This will ensure equal elapsed time for each pipetting step, without interruption. Duplication of all specimens, although not required, is recommended. To avoid cross-contamination, change pipette tips between sample additions, and between reagent additions. Also, use separate reservoirs for each reagent.
3. Incubation: To ensure accurate results, proper adhesion of plate sealers during incubation steps is necessary. Do not allow wells to sit uncovered for extended periods between incubation steps. Once reagents have been added to the well strips, DO NOT let the strips DRY at any time during the assay. Incubation time and temperature must be observed.
4. Washing: The wash procedure is critical. Complete removal of liquid at each step is essential to good performance. After the last wash, remove any remaining Wash Solution by aspirating or decanting and remove any drop of water and fingerprint on the bottom of the plate. Insufficient washing will result in poor precision and falsely elevated absorbance reading. When using an automated plate washer, adding a 30 second soak period following the addition of wash buffer, and/or rotating the plate 180 degrees between wash steps may improve assay precision.
5. Controlling of reaction time: Observe the change of color after adding TMB Substrate (e.g. observation once every 10 minutes), TMB Substrate should change from colorless or light blue to gradations of blue. If the color is too deep, add Stop Solution in advance to avoid excessively strong reaction which will result in inaccurate absorbance reading.
6. TMB Substrate is easily contaminated. TMB Substrate should remain colorless or light blue until added to the plate. Please protect it from light.
7. Stop Solution should be added to the plate in the same order as the TMB Substrate. The color developed in the wells will turn from blue to yellow upon addition of the Stop Solution. Wells that are green in color indicate that the Stop Solution has not mixed thoroughly with the TMB Substrate.

CALCULATION OF RESULTS

For calculation the valence of human HBV preS1-Ag, compare the sample well with control.

- (1) Blank OD value must no more than 0.08.
- (2) The average Negative Control value must less than 0.1. If the average value of $OD_{\text{negative}} < 0.05$, calculate it as 0.05.
- (3) Positive Control OD Value must more than 0.30.
- (4) A cutoff value was defined as the average Negative Control value plus 0.10.
 - While $OD_{\text{sample}} < \text{Cutoff Value}$: Negative
 - While $OD_{\text{sample}} \geq \text{Cutoff Value}$: Positive

人乙型肝炎病毒前 S1 抗原(HBV preS1-Ag)酶联免疫试剂盒

使用说明书

【产品编号】CSB-EQ028068HU

【预期应用】ELISA 法评价人血清、血浆中 HBV preS1-Ag 效价。

【产品性能指标】

- 1、 精密度：批内差 CV%<15%，批间差 CV%<15%
- 2、 特异性：本试剂盒特异性检测人 HBV preS1-Ag。

【实验原理】

用抗 preS1 的抗体包被酶标板，制成固相载体。向微孔中先加入待测样品进行反应，然后再加入辣根过氧化物酶标记抗-HBs 进行反应，经过彻底洗涤后用底物显色。底物在过氧化物酶的催化下转化成蓝色，并在酸的作用下转化成最终的黄色。颜色的深浅和样品中的 HBV preS1-Ag 呈正相关。用酶标仪在 450nm 波长下测定吸光度（OD 值），与阴性对照孔判断样品中 HBV preS1-Ag 效价。

【试剂盒组成成分】

组份	装量
酶标板 (Assay plate)	96 孔
阴性对照(Negative Control)	1 x 0.4 ml/瓶
阳性对照(Positive Control)	1 x 0.4 ml/瓶
酶结合物 (HRP-conjugate)	1 x 6 ml/瓶
浓洗涤液 (Wash Buffer)	1 x 50 ml/瓶 (20×)
底物溶液 A (Substrate A)	1 x 6 ml/瓶
底物溶液 B (Substrate B)	1 x 6 ml/瓶
终止液 (Stop Solution)	1 x 6 ml/瓶
板贴	4

【存储条件及有效期】

1. 未开封的试剂盒避光保存于2-8℃。有效期为六个月。请在试剂盒标注的有效日期内使用。
2. 酶标板打开后应置有干燥剂的铝箔袋中置于2-8℃密封防潮保存，2-8℃条件下最多可保存一个月。

【所需试剂和器材】

标准规格酶标仪；高速离心机；电热恒温培养箱；干净的试管和离心管；容量瓶；

系列可调节移液器及吸头；多通道移液器；蒸馏水 等

【样本采集及保存】

1. 血清：全血标本请于室温放置2小时或4℃过夜后于1000g离心15分钟，取上清即可立即检测；或进行分装，并将标本放于-20℃或-80℃保存，但应避免反复冻融。解冻后的样品应再次离心，然后检测。
2. 血浆：可用EDTA或肝素作为抗凝剂，标本采集后30分钟内于2-8℃1000 x g离心15分钟，取上清即可立即检测；或进行分装，并将标本放于-20℃或-80℃保存，但应避免反复冻融。解冻后的样品应再次离心，然后检测。

注：标本溶血会影响最后检测结果，因此溶血标本不宜进行此项检测。

【试剂配制】

洗液工作液：洗液需提前配制，稀释前根据预先计算好的每次实验所需的总量配制。取出洗液浓缩液，浓洗涤液低温保存会有盐析出，稀释时可在水浴中加温助溶。浓洗涤液按1:20倍进行稀释。例如用量筒量取950ml去离子水，倒入烧杯或其他洁净容器中，再量取50ml浓洗涤液，均匀加入，搅拌均匀。

【注意事项】

1. 实验开始前，请提前配置好所有试剂。试剂或样品稀释时，均需混匀，混匀时尽量避免起泡。
2. 用户在初次使用试剂盒时，应将各种试剂管离心数分钟，以便试剂集中到管底。

【操作步骤】

1. 将各种试剂移至室温（18-25℃）平衡至少 30 分钟，按前述方法配制试剂，备用。
2. 将酶标板取出，设一个空白对照孔、不加任何溶液；设 3 个阴性对照、1 个阳性对照，加阴性对照、阳性对照各 50 μ l；其余样本检测孔每孔加 50 μ l 的待测样本。
3. 充分混匀，贴上不干胶封片，置 37℃温育 30 分钟。
4. 弃去孔内液体，甩干，洗板 5 次。每次浸泡 30-60 秒，200 μ l/孔，甩干。
5. 每孔加入酶结合物 50 μ l（空白对照孔除外），充分混匀，贴上不干胶封片，置 37℃温育 30 分钟。
6. 弃去孔内液体，甩干，洗板 5 次。每次浸泡 30-60 秒，200 μ l/孔，甩干。
7. 每孔加底物溶液 A 和 B 各 50 μ l，振荡混匀后，37℃避光显色 15 分钟，每孔加终止液 50 μ l。
8. 空白孔调零，用酶标仪在 450nm 波长依序测量各孔的光密度（OD 值）。在反应终止后 10 分钟内进行检测。

【操作要点】

- 1、为保证检测结果的准确性，建议样本均设双孔测定。
- 2、**加样**：加样时，请使用一次性的洁净吸头，避免交叉污染。加样时应尽量轻缓，避免起泡，将样本加于酶标板孔底部，切勿沿孔壁加样。一次加样时间最好控制在 10 分钟内，如标本数量多，推荐使用排枪加样。
- 3、**温育**：为防止样本蒸发或污染，温育过程中酶标板必须覆上板贴，实验过程中酶标板应避免处于干燥的状态。温育过程中应随时观察温箱温度是否恒定于 37℃，及时调整。温育过程中，温箱不易开启太多次，以免影响温度平衡。
- 4、**洗涤**：洗涤过程非常重要，不充分的洗涤易造成假阳性。
 - (1) 手工洗板方法：吸去（不可触及孔壁和孔底）或甩掉酶标板内的液体；在实验台上铺垫几层吸水纸，酶标板朝下轻拍几次；将推荐的洗涤缓冲液按 200 μ l/孔注入孔内，浸泡 30-60 秒。根据操作步骤中所述，重复此过程数次。
 - (2) 自动洗板：如果有自动洗板机，应在熟练使用后再用到正式实验过程中。
- 5、**显色**：为保证实验结果的准确性，底物反应时间到后应尽快加入终止液。可在加入底物溶液后每隔一段时间观察一下显色情况以控制反应时间（比如每隔 10 分钟）。当肉眼可见明

显蓝色，即可加入终止液终止反应，此时蓝色立刻变为黄色。终止液的加入顺序应尽量与底物溶液的加入顺序相同。

- 6、底物溶液应为浅蓝色或无色，如果颜色严重变深则必须弃用。底物溶液易受污染，请避光妥善保存。

【数据处理】

- 1、空白孔的 OD 值 ≤ 0.08
- 2、阴性对照孔的平均 OD 值 < 0.1 （若阴性对照孔平均 OD 值小于 0.05，则按 0.05 计算）。
- 3、阳性对照孔的 OD 值 > 0.30
- 4、判断值 $= 0.10 + \text{阴性孔平均 OD 值}$
- 5、结果判定：样本 OD 值大于等于判断值为阳性，小于判断值为阴性。

【说明】

- 1、本试剂盒仅供研究使用。
- 2、中、英文说明书可能会有不一致之处，请以英文说明书为准。
- 3、不同批号试剂不能混用。不要用其它生产厂家的试剂替换试剂盒中的试剂。
- 4、刚开启的酶标板孔中可能会含有少许水样物质，此为正常现象，不会对实验结果造成任何影响。
